

Part Number: **1780720**

Product Description: **BED RACK TWIN SUPPORT MOUNT**Used With: **1780710 BED RACK SINGLE MOUNT**

WARNING

NOTE THE FOLLOWING:

- Vehicle accessories which are not properly fitted can be dangerous.
- Please read these instructions carefully prior to fitting, and comply with the instructions at all times
- If in any doubt please contact your nearest ARB state office or the stockist from whom it was purchased.
- Do not use this product for any vehicle make or model, other than those specified by ARB.
- This product or its fixing must not be modified in any way.
- ◆ The installation of this product may require the use of specialized tools and/or techniques.
- It is recommended that this product is only installed by trained personnel.
- ♦ These instructions are correct as at the publication date. ARB Corporation Ltd. cannot be held responsible for the impact of any changes subsequently made by the vehicle manufacturer.
- During installation, it is the duty of the installer to check correct operation/clearances of all components.
- Work safely at all times.
- Unless otherwise instructed, tighten fasteners to specified torque.
- Check bolt torque after 500km & at regular service intervals.

ARB 4x4 ACCESSORIES

Corporate Head Office

42-44 Garden St Kilsyth, Victoria AUSTRALIA 3137 Tel: +61 (3) 9761 6622 Fax: +61 (3) 9761 6807

Australian enquiries North & South American enquiries Other international enquiries sales@arb.com.au sales@arbusa.com exports@arb.com.au

www.arb.com.au

Last Rev Date: 26/09/2023 Page 1 of 6 Fitting instructions# 37801314

SAFETY

- The maximum load per twin support mount is 20.0kg.
- Attachments must not project beyond the overall width of the vehicle.
- Attachments can be either side of the mount or spread over both sides.
- Any weight carried on the BED RACK will adversely affect its handling, particularly in cornering or in a cross-wind, the vehicle should therefore be driven with increased discretion.
- Regularly check the tightness of the securing clamps and the security of the load.
- If accessories are attached to the bed rack, at least one cross bar must be fitted at all times.

GENERAL CARE AND MAINTENANCE

By choosing an ARB BED RACK, you have bought a product that is one of the most sought after 4WD products in the world. Your BED RACK is a properly engineered, reliable, quality accessory that represents excellent value. To keep your BED RACK in original condition it is important to care and maintain it following these recommendations:

 As part of any pre-trip preparation, or on an annual basis, it is recommended that a thorough visual inspection of the BED RACK is carried out, making sure that all bolts and other components are torqued to the correct specification. Replace any components as necessary.

Please contact local Authorised ARB Stockist if you would like to have this service carried out on your behalf.

FITTING REQUIREMENTS

REQUIRED TOOLS FOR FITMENT OF PRODUCT:

METRIC SOCKET SET	TORQUE WRENCH Minimum 22Nm




SIZE	SIZE Torque Nm Torque Ib	
M8	22Nm	16lbft


PARTS LISTING – BED RACK CROSS BAR FITTING KIT			
PART NUMBER	DESCRIPTION	QTY	DIAGRAM
3752562	BRKT RT ACC CLAMP 100MM	1	888
3755342	TWIN SUPPORT BRKT BED RACK	1	
4581085	WASHER FLAT M8X19X1.2	2	
6151212	NUT HEX NYLOC M8X1.25	2	
6151921	BOLT COHD M8X20	2	
6151730	BOLT HXHD FL M8x1.25x20	4	

BEFORE STARTING, READ ALL STEPS OF THE INSTRUCTIONS


1. Place clamping plate inside of the mount and Install M8 coach head screws, washers and nyloc nuts as shown.

Leave finger tight.







2. Install the assembled mount to the dovetail, centre with the single mount and rotate to align.



3. Install four M8 x 20 FL bolts, two per side, and tighten to be firm.



- 4. Single mount M8 Nyloc Nuts are accessed through holes provided in mount.
- 5. Twin Support M8 Nyloc Nuts are accessed through holes provided on angled face.



- 6. Align assembled mounts to the appropriate position and torque fasteners to specification in the following order:
 - a. Single mount fasteners.
 - b. Twin mount fasteners.
 - c. M8 FL bolts in four places

M8 - **22 Nm.**

